Handling a Temperature Excursion in Your Vaccine Storage Unit

Follow the steps below following any temperature reading outside the ranges of 36° to 46°F (2° to 8°C) for FRIDGES or -58°F to 5°F (-50°C to -15°C) for FREEZERS.

