


1 Store vaccine at ideal temperature: 40°F

Never freeze refrigerated vaccine!
Exception: MMR can be stored in fridge or freezer



Report out of range temperatures immediately!

2 Record daily temperatures

Check and record the temperatures and alarm status (lights) of your data logger TWICE DAILY – first thing in the morning and before leaving at the end of the day.

Morning AM:

Press #1: Current temperature (X)

Press #2: Maximum recorded temperature (▲) since last reset (M)

Press #3: Minimum recorded temperature (▼) since last reset (M)

Press #4 and Hold: CLr▲▼ appears after 3–5 seconds. Resets min/max temperatures.

Check Light: Is it green? (Y or N)

Evening PM:

Press #1: Current temperature (X)

Check Light: Is it green? (Y or N)

Data Logger Display



Paper Temperature Log

Day of Month	1		2		3	
Time of Day	am	pm	am	pm	am	pm
	9	5	9	5	9	5
Staff Initials	bl	gl	bl	bl	bl	bl
LED Green?	Y	Y	Y	Y	Y	Y
	≥50°					Y
	49°		DO NOT USE vac			
	48°					
(C)	47°					
	46°					
8°	45°					
	44°					
7°	43°					
	42°					
6°	41°					
	40°				M	
5°						M
	39°		M		X	
4°	38°			X	X	X
	37°		X			X
3°	36°					M
	35°					
2°	34°					
	33°		DO NOT USE vac			
	32°					
	31°					



3 Take action if out of range!

Public Vaccine: Report **red lights** and out-of-range temperatures immediately to the Immunization Program.

Go to www.immunization.mt.gov and click on "Vaccine Incident Report"

Private Vaccine:* Call manufacturers directly with the following information:

- Total time vaccine was out of range
- Maximum or minimum temperature achieved

*If the incident involves public and private vaccine, call the Immunization Program first. Our calls to manufacturers on public vaccine may also apply to your private vaccine.



Best Practices

- **Take your time:** Read and record temperatures accurately.
- **Make your mark:** Initial the log when recording temperatures.
- **Leave it blank:** If a temperature was not recorded, leave the space blank!